


National Sun Yat-sen University Power Kiosk User Guide

ORing Industrial Networking Corp.

2024.10



— Instructions for Recharge Operations


1. System Homepage



- Explanation :
 - (1) Upper Area: The left side displays the name, while the right side shows the time.
 - (2) Middle Area: The left side features the latest announcements, and the right side contains the function menu.
 - (3) Lower Area: Displays the machine location, number, and version information.
- Operation :
 - (1) To Recharge: Click the "Power Card Add Value" button.
 - (2) To Purchase a Card: Click the "Power Card Purchase" button.
 - (3) To Report a Malfunction: Click the "Repair Form" button.

☐ • Power Card Recharge

1. System Homepage



- Operation :
 - (1) Click on "Power Card Add Value"

2. Insert the power card for verification.



- Operation :
 - (1) Insert the power card for verification.
 - (2) If verification is successful, the screen will navigate to the payment page.
 - (3) If there is an error, an error message will be displayed, such as "Card verification failed. Please use the designated power card..." and other relevant information.

3. Once the power card verification is successful, select the payment method.

National Sun Yat-sen University		2024/10/25 16:47:04
Power Card Info Card Number : 00000001 Type : Power Card Card Balance : NT\$ 715 (Add value limit : NT\$ 2000)	Power Card Add Value STEP-1 : Select Payment	Cash
Last 5 transaction records 2024/10/25 16:26 NT\$ 100 2024/10/25 16:24 NT\$ 100 2024/10/16 15:25 NT\$ 100 2024/10/09 17:09 NT\$ 100 2024/10/09 17:09 NT\$ 100	Finish Add Val	ue Next
Kiosk Id: 1 Version: 202409.01 (Number of cards: 29)	(Card sales are normal)	

- Explanation :
 - (1) Left Area:


The upper section displays power card information, including card number, balance, recharge limit, and other details.

The lower section shows the last 5 transaction records.


- (2) Right Area: Select the payment method, which includes "iPASS Card" and "Cash"
- Operation :
 - (1) To make an iPASS Card payment: Select " iPASS Card," confirm, and then click the "Next" button.
 - (2) To make a cash payment: Select "Cash," confirm, and then click the "Next" button.

4. iPASS Card Payment Page


• Select the amount, and once confirmed, click the "Next" button.



• Hold the iPASS Card close to the card reader to process the payment.



• Payment completed, displaying the transaction results for both the iPASS Card and the power card.



5. Cash Payment Page



• Explanation :

(1) Left Area:

The upper section displays power card information, including card number, type, card balance, and maximum recharge limit. The lower section shows the most recent recharge records for the power card.


(2) Right Area:

Displays instructions for the recharge operation, including the remaining amount that can be recharged, acceptable denominations of banknotes, and a no-change policy.

• Operation :

- To Recharge: Directly insert "banknotes" to proceed with the recharge. If you wish to continue recharging, insert additional "banknotes."
- (2) To End Recharge: Click the "Finish Add Value" button.

6. Print Receipt



- Explanation :
 - (1) When the recharge process is completed, the system will prompt whether to print a receipt.
- Operation :
 - (1) To Print Receipt: Click the "Print Receipt" button.
 - (2) To Not Print Receipt: Click the "Home" button.


Ξ · Purchase of Power Card

1. System Home Page



- Operation :
 - (1) Click on "Power Card Purchase"


2. Choose Payment Method



- Operation :
 - (1) For iPASS Card payment: Select 'iPass Card', confirm, and then click the 'Next' button.
 - (2) For cash payment: Select 'Cash Payment', confirm, and then click the 'Next' button.

3. iPASS Card Payment Page

• Tap the iPASS Card on the card reader for payment.




• Payment completed. Retrieve the Power Card at the exit below.




4. Cash Payment Page

• Insert the cash amount for the card (the machine does not provide change).




• Payment completed. Retrieve the Power Card at the exit below.




四、 Fault Reporting

1. System Home Page



- Operation :
 - (1) Click on Repair Form

2. Enter Student ID




3. Dormitory Room Number




4. Contact Phone Number

National Sun Yat-sen University	2024/10/25 16:53:12
Repair Form Student ID : A3289401 Dormitory : 武嶺二村(Wu-ling 2)-2016 Contact number : Time of occurrence : Problem : PowerCard Number : IPassCard Number :	Fill out the Repair Form STEP-3 : Contact number Phone Number 0943001234 (-) 1 2 3 4 5 6 7 8 9 0 Home Previous Next
Kiosk Id: 1 Version: 202409.01 (Number of cards : 27) (Card sales are norm	nal)


5. Time of Occurrence



6. Description of the Issue



7. Power Card Number




8. iPASS Card Number

 After pressing the 'Click to tap card' button, bring the iPASS Card close to the card reader to read the card number.



9. After confirming that the information is correct, press the "Submit" button.



10.Repair request submitted successfully. The dormitory management team will follow up to verify the issue and contact the student.

